

# SEIKO

## PROFESSIONAL TUNERS & METRONOMES



# SEIKO Tuners & Metronomes

## Tuners

### Road Ready Chromatic Tuner

## SAT800

'Heavy Duty Tuner' with Large Backlit Display

- Tuning Range : A0~C8
- Sound Generation : C4~B4 (1 octave)
- Pitch Shift : A4=410~450Hz (1Hz step)
- Line-in/ Line-out
- Shock Absorbing Non-slip Rubber shielding
- Large Backlit Display
- Aluminium Front Panel
- Intuitive Buttons for Easy Operation



### Professional High Accuracy Tuner with Ultra-Thin VU Meter Style Meter

## SAT1100

Compact Design with user friendly buttons and Functions for Easy Operation

- Tuning Range : A0~C8
- Sound Generation : C4~B4 (1 octave)
- Pitch Shift : A4=410~450Hz (1Hz step)
- Large clear VU Meter
- Power Reserve Indicator
- Pointer Position Calibration
- Line-in/ Line-out
- 3-position Cover (stand, cover, and music-stand hanger)



## Tuner & Metronome

### Versatile Clip-On Provides Accurate Tuning and Perfect Rhythm

## STMX1

Clip-on Tuner & Metronome with Backlit LCD Display

#### Tuner

- Tuning Range : A0~C8
- Sound Generation : C4~B4 (1 octave)
- Pitch Shift : A4=410~450Hz (1Hz Step)
- Biaxial Swivel Arm Enables Head-on View of the Display



#### Metronome

- Tempo Range : 30~250 (221 steps)
- Beat : 0, 1, 2, 3, 4, 5, 6, 7, 8, 9
- Rhythm :
- Volume Control



### Innovative sensitivity modulation function effectively eliminates background interference

**NEW**

## STX2

Clip-on Tuner Stylish display can be reversed for left or right hand play

- Tuning Range : A0~C8
- Pitch Shift : A4=415, 435~446Hz
- Clear and Bright Back-lit Display



### Stylish chromatic tuner with long battery life

**NEW**

## SAT501

Larger display and brighter LEDs for improved visibility intuitive layout for ease of operation

- Tuning Range : A0~C8
- Sound Generation : C4~B4 (1 octave)
- Pitch Shift : A4=410~450Hz
- Line-in/ Line-out

#### Accessories

#### ●STM20

Clip-on Pick Up Microphone Attachable as an Option



### Stunning Black Guitar /Bass Tuner with long battery life

**NEW**

## SAT101

Improved intuitive layout for ease of operation

- Tuning Range :  
Guitar : 7B, 6E, 5A, 4D, 3G, 2B, 1E  
Bass : LowB, 4E, 3A, 2D, 1G, HiC
- Sound Generation :  
Guitar : 7B, 6E, 5A, 4D, 3G, 2B, 1E (1 octave higher)  
Bass : LowB, 4E, 3A, 2D, 1G, HiC (2 octave higher)
- Pitch Shift : A4=435~446Hz (1Hz Step)
- Line-in/ Line-out

#### Accessories

#### ●STM20

Clip-on Pick Up Microphone Attachable as an Option



### Ultra Compact Tuner Goes Everywhere You Go

## ST01·ST02

Stylish Key Ring Auto-Chromatic Tuner

- Pitch Shift : ST01 A4=440Hz, ST02 A4=442Hz
- Tuning Range : A0~C8
- Auto Tuning Mode with Built in Microphone
- Auto Power-off : 2min. without sensing a note

TUNING STICK  
ST01  
A4=440Hz



TUNING STICK  
ST02  
A4=442Hz



## Metronomes

Beautifully lacquered wooden mechanical metronome

**NEW**

### WPM2000

SPRUCE wood-case offers resonant and profound sound

- Tempo Range : 40~208 (39 Steps)
- Beat : 0, 2, 3, 4, 6
- Rich Resonant Sound



Piano Black(BK)

Elegant spruce wood-case enhances profound and resonant sound

### WPM1000

Perfect for Discerning Teachers and Students

- Tempo Range : 40~208 (39 Steps)
- Beat : 0, 2, 3, 4, 6
- Rich Resonant Sound



Brown (B)



Light Brown(N)

High quality sound with stylish colors

### SPM320 · SPM370

Mechanical Metronome

- Tempo Range : 40~208 (39 Steps)
- Beat : 0, 2, 3, 4, 6




SPM320 PureWhite (W)



SPM320 LimeGreen (G)



SPM320 CherryPink (C)



SPM320 SkyBlue (M)



SPM320 Black (B)



SPM370 Milky Blue (SB)



SPM370 Translucent Yellow (SY)



SPM370 Translucent Red (SR)

Compact metronome with clear, loud sound

### DM50

Clip-on Digital Metronome

- Tempo Range : 30~250 (221 Steps)
- Beat : 0, 1, 2, 3, 4, 5, 6, 7
- Rhythm :
- Volume Control (4 levels)
- Clock Function



Silver Metallic (S)



Red Metallic (R)



Blue Metallic (L)



Portable and Versatile

### DM70

Pocket-Sized Digital Metronome

- Tempo Range : 30~250 (221 Steps)
- Beat : 0, 1, 2, 3, 4, 5, 6, 7
- Rhythm :
- Sound Generation : C4~B4 (A4=440Hz)
- Volume Control (4 levels)
- Built-in Stand



Silver (S)



Blue (L)



Black (B)

Highly visible tempo indicator with scanning lights

### DM100

Multi-Function Digital Metronome with Tap in beat Function

- Tempo Range : 30~250 (221 Steps)
- Beat : 0, 1, 2, 3, 4, 5, 6, 7
- Rhythm :
- Sound Generation : C4~B4, A4=410~450Hz
- Volume Control
- TAP Function
- Back Slot to Fit and Slide Easily onto Music Stand
- Built-in Stand



Silver (S)



Black (B)



High Quality Sound from Dynamic Speaker with Volume Control

### SQ50V

Quartz Metronome with Easy to operate Tempo Dial

- Tempo Range : 40~208 (39 Steps)
- Sound Generation : A4 (440Hz), B♭4 (466.16Hz)
- Volume Control
- Two Types of Tempo Sounds



Multi-Function Quartz Metronome with a clear, loud sound

### SQ70

Scanning Tempo Indicator with 9LEDs and Tempo Dial

- Tempo Range : 40~208 (39 Steps)
- Beat : 0, 1, 2, 3, 4, 5, 6
- Sound Generation : A4 (440~446Hz), B♭4 (466.16Hz)
- Volume Control
- Two Types of Tempo and Beat Sounds



# SEIKO Specifications

Tuners								Tuner & Metronome
	SAT1100	SAT800	STX2	ST01	ST02	SAT501	SAT101	STMX1
<b>Tuning Method (Mode)</b>	<ul style="list-style-type: none"> <li>•Auto-Chromatic Mode</li> <li>•Manual-Chromatic Mode</li> <li>•Sound Mode</li> </ul>		•Auto-Chromatic Mode	•Auto-Chromatic Mode		<ul style="list-style-type: none"> <li>•Auto-Chromatic Mode</li> <li>•Manual-Chromatic Mode</li> <li>•Sound Mode</li> </ul>	<ul style="list-style-type: none"> <li>•Auto Tuning Mode</li> <li>•Manual Tuning Mode</li> <li>•Sound Mode</li> </ul>	<ul style="list-style-type: none"> <li>•Auto-Chromatic Mode</li> <li>•Manual-Chromatic Mode</li> <li>•Sound Mode</li> </ul>
<b>Tuning Range</b>	A0 (27Hz)~C8 (4186Hz) (Note=C,C#,D,D#,E,F,F#,G,G#,A,A#,B)	A0 (27Hz)~C8 (4186Hz) (Note =C,C#,D,D#,E,F,F#,G,G#,A,A#,B)	A0 (27Hz)~C8 (4186Hz) (Note = C,C#,D,D#,E,F,F#,G,G#,A,A#,B)	A0 (27Hz)~C8 (4186Hz) (Note = C,C#,D,D#,E,F,F#,G,G#,A,A#,B)		A0 (27Hz)~C8 (4186Hz) (Note = C,C#,D,ED,E,F,F#,G,G#,A,Bb,B)	<ul style="list-style-type: none"> <li>•Guitar : 7B,6E,5A,4D,3G,2B,1E</li> <li>•Bass : LowB,4E,3A,2D,1G,HIC</li> </ul>	A0 (27Hz)~C8 (4186Hz) (Note = C,C#,D,D#,E,F,F#,G,G#,A,A#,B)
<b>Sound Generation</b>	C4~B4 (12 Notes)	C4~B4 (12 Notes)	————	————		C4~B4 (12 Notes)	<ul style="list-style-type: none"> <li>•Guitar : 7B,6E,5A,4D,3G,2B,1E (1 octave higher)</li> <li>•Bass : LowB,4E,3A,2D,1G,HIC (2 octave higher)</li> </ul>	C4~B4 (12 Notes)
<b>Pitch Shift</b>	A4 = 410~450Hz (1Hz Step)		A4 = 415Hz,435~446Hz (1Hz Step)	A4 = 440Hz	A4 = 442Hz	A4 = 410~450Hz (1Hz Step)	A4 = 435~446Hz (1Hz Step)	A4 = 410~450Hz (1Hz Step)
<b>Indicator</b>	<ul style="list-style-type: none"> <li>•LCD Display : Power reserve indicator, Backlight mode mark, Mode Indication, Pitch indication</li> <li>•2 LEDs : Tuning Guide</li> <li>12LEDs : Note Indication</li> </ul>	<ul style="list-style-type: none"> <li>•LCD Display : Analogous Meter (+/-50 Cent), Digital Cent Indication (+/-50 Cent), Calibration Indication, Mode Indication, Note Indication</li> <li>•3 LEDs : Tuning Guide</li> </ul>	<ul style="list-style-type: none"> <li>•LCD Display : Note Indication, Pitch Indication</li> <li>•9 LEDs : Tuning Guide</li> </ul>	<ul style="list-style-type: none"> <li>•LCD Display : Note Indication</li> <li>•1 LED : Tuning Guide</li> </ul>		<ul style="list-style-type: none"> <li>•String Name Indication (SAT101)</li> </ul>		<ul style="list-style-type: none"> <li>•LCD Display : Mode Indication, Note Indication</li> <li>•7 LEDs : Tuning Guide</li> </ul>
<b>Terminal</b>	<ul style="list-style-type: none"> <li>•Built-in Microphone</li> <li>•Input-Jack</li> <li>•Output-Jack</li> </ul>	<ul style="list-style-type: none"> <li>•Input-Jack</li> <li>•Output-Jack</li> </ul>	<ul style="list-style-type: none"> <li>•Built-in Vibration Sensor</li> <li>•Sensitivity Modulate Function</li> </ul>	<ul style="list-style-type: none"> <li>•Built-In Microphone</li> </ul>		<ul style="list-style-type: none"> <li>•Built-in Microphone</li> <li>•Input-Jack</li> <li>•Output-Jack</li> </ul>	<ul style="list-style-type: none"> <li>•Input-Jack</li> <li>•Output-Jack</li> </ul>	<ul style="list-style-type: none"> <li>•Built-in Vibration Sensor</li> <li>•Built-in Microphone</li> </ul>
<b>Others</b>	<ul style="list-style-type: none"> <li>•Auto Power-Off</li> <li>•Memory Back Up</li> <li>•Pointer Position Calibration</li> </ul>	<ul style="list-style-type: none"> <li>•Auto Power-Off</li> <li>•Memory Back Up</li> <li>•Backlight</li> </ul>	<ul style="list-style-type: none"> <li>•Auto Power-Off</li> <li>•Memory Back Up</li> </ul>	<ul style="list-style-type: none"> <li>•Auto Power-Off</li> </ul>		<ul style="list-style-type: none"> <li>•Auto Power-Off</li> <li>•Memory Back Up</li> </ul>	<ul style="list-style-type: none"> <li>•Auto Power-Off</li> <li>•Memory Back Up</li> </ul>	<ul style="list-style-type: none"> <li>•Auto Power-Off</li> <li>•Memory Back Up</li> </ul>
<b>Battery</b>	R03/LR03(AAA)×2(3V) included		Lithium Battery(CR2032×1) included	Lithium Battery(CR1220×1) included		R03/LR03(AAA)×2(3V) included		————

Metronomes								
	WPM1000・2000	SPM320・370	SQ70	SQ50V	DM100	DM70	DM50	
<b>Tempo Range</b>	40~208 times/min.(39 Steps)				30~250 times/min.(221 Steps)			30~250 times/min.(221 Steps)
<b>Beat and Rhythm</b>	0,2,3,4,6	————	0,1,2,3,4,5,6	————	0,1,2,3,4,5,6,7	0,1,2,3,4,5,6,7	0,1,2,3,4,5,6,7,8,9	
<b>Sound Generation</b>	————	————	A4 = 440~446Hz (1Hz Step)	A4 = 440Hz B♭4 = 466.1Hz	C4~B4 (12 Notes) A4 = 410~450Hz (1Hz Step)	C4~B4 (12 Notes) A4 = 440Hz	————	A4 = 410~450Hz (1Hz Step)
<b>Tempo &amp; Beat Sound</b>	Click & Bell		2 different selectable tones		Click Sound	Beep		
<b>Indicator</b>	————	————	9 LEDs	1 LED	5 LEDs & LCD	1 LED & LCD	7 LEDs & LCD	
<b>Terminal</b>	————	————	<ul style="list-style-type: none"> <li>•Earphone Jack (φ 3.5mm)</li> <li>•AC Adapter Jack (DC9V)</li> </ul>	<ul style="list-style-type: none"> <li>•Earphone Jack (φ 3.5mm)</li> </ul>	<ul style="list-style-type: none"> <li>•Earphone Jack (φ 2.5mm)</li> </ul>	————	————	
<b>TAP Function</b>	Tempo Range	————	————	————	30~250	————	————	
	Rhythm	————	————	————	♪ ♪ ♫ ♬	————	————	
<b>Others</b>	————	————	<ul style="list-style-type: none"> <li>•Volume Control</li> <li>•Memory Back Up</li> </ul>	<ul style="list-style-type: none"> <li>•Volume Control</li> </ul>	<ul style="list-style-type: none"> <li>•Volume Control</li> <li>•Memory Back Up</li> </ul>	<ul style="list-style-type: none"> <li>•Volume Control (4levels)</li> <li>•Memory Back Up</li> </ul>	<ul style="list-style-type: none"> <li>•Volume Control (4levels)</li> <li>•Clock</li> <li>•Memory Back Up</li> </ul>	<ul style="list-style-type: none"> <li>•Auto Power-Off</li> <li>•Volume Control</li> <li>•Memory Back Up</li> </ul>
<b>Battery</b>	————	————	9V Dry Battery (6F22) included		R03/LR03(AAA)×2 included	Lithium Battery(CR2025×1) included		Lithium Battery(CR2032×1) included

Accessories	
	STM-20
<b>Terminal</b>	Input-Jack (φ 6mm)
<b>Cable Length</b>	150cm

AVAILABLE AT:

**SEIKO** SEIKO SPORTS LIFE CO.,LTD.

17-8,Nishikata 1-chome,Bunkyo-ku,Tokyo 113-0024, Japan  
<http://www.seiko-sl.co.jp/music>

SEIKO IS A REGISTERED TRADEMARK OF SEIKO HOLDINGS CORPORATION, JAPAN.