

SEIKO

PROFESSIONAL TUNERS & METRONOMES



SEIKO Tuners & Metronomes

Tuners

Road Ready Chromatic Tuner

SAT800

'Heavy Duty Tuner' with Large Backlit Display

- Tuning Range : A0~C8
- Sound Generation : C4~B4 (1 octave)
- Pitch Shift : A4=410~450Hz (1Hz step)
- Line-in/ Line-out
- Shock Absorbing Non-slip Rubber shielding
- Large Backlit Display
- Aluminium Front Panel
- Intuitive Buttons for Easy Operation



Professional High Accuracy Tuner with Ultra-Thin VU Meter Style Meter

SAT1100

Compact Design with user friendly buttons and Functions for Easy Operation

- Tuning Range : A0~C8
- Sound Generation : C4~B4 (1 octave)
- Pitch Shift : A4=410~450Hz (1Hz step)
- Large clear VU Meter
- Power Reserve Indicator
- Pointer Position Calibration
- Line-in/ Line-out
- 3-position Cover (stand, cover, and music-stand hanger)



Tuner & Metronome

Versatile Clip-On Provides Accurate Tuning and Perfect Rhythm

STMX1

Clip-on Tuner & Metronome with Backlit LCD Display

Tuner

- Tuning Range : A0~C8
- Sound Generation : C4~B4 (1 octave)
- Pitch Shift : A4=410~450Hz (1Hz Step)
- Biaxial Swivel Arm Enables Head-on View of the Display



Metronome

- Tempo Range : 30~250 (221 steps)
- Beat : 0, 1, 2, 3, 4, 5, 6, 7, 8, 9
- Rhythm :
- Volume Control



Innovative sensitivity modulation function effectively eliminates background interference

NEW

STX2

Clip-on Tuner Stylish display can be reversed for left or right hand play

- Tuning Range : A0~C8
- Pitch Shift : A4=415, 435~446Hz
- Clear and Bright Back-lit Display



Stylish chromatic tuner with long battery life

NEW

SAT501

Larger display and brighter LEDs for improved visibility intuitive layout for ease of operation

- Tuning Range : A0~C8
- Sound Generation : C4~B4 (1 octave)
- Pitch Shift : A4=410~450Hz
- Line-in/ Line-out

Accessories

●STM20

Clip-on Pick Up Microphone Attachable as an Option



Stunning Black Guitar /Bass Tuner with long battery life

NEW

SAT101

Improved intuitive layout for ease of operation

- Tuning Range :
Guitar : 7B, 6E, 5A, 4D, 3G, 2B, 1E
Bass : LowB, 4E, 3A, 2D, 1G, HiC
- Sound Generation :
Guitar : 7B, 6E, 5A, 4D, 3G, 2B, 1E (1 octave higher)
Bass : LowB, 4E, 3A, 2D, 1G, HiC (2 octave higher)
- Pitch Shift : A4=435~446Hz (1Hz Step)
- Line-in/ Line-out

Accessories

●STM20

Clip-on Pick Up Microphone Attachable as an Option



Ultra Compact Tuner Goes Everywhere You Go

ST01 · ST02

Stylish Key Ring Auto-Chromatic Tuner

- Pitch Shift : ST01 A4=440Hz, ST02 A4=442Hz
- Tuning Range : A0~C8
- Auto Tuning Mode with Built in Microphone
- Auto Power-off : 2min. without sensing a note

TUNING STICK
ST01
A4=440Hz



TUNING STICK
ST02
A4=442Hz



Metronomes

Beautifully lacquered wooden mechanical metronome

NEW

WPM2000

SPRUCE wood-case offers resonant and profound sound

- Tempo Range : 40~208 (39 Steps)
- Beat : 0, 2, 3, 4, 6
- Rich Resonant Sound



Piano Black(BK)

Elegant spruce wood-case enhances profound and resonant sound

WPM1000

Perfect for Discerning Teachers and Students

- Tempo Range : 40~208 (39 Steps)
- Beat : 0, 2, 3, 4, 6
- Rich Resonant Sound



Brown (B)



Light Brown(N)

High quality sound with stylish colors

SPM320 · SPM370

Mechanical Metronome

- Tempo Range : 40~208 (39 Steps)
- Beat : 0, 2, 3, 4, 6



SPM320 PureWhite (W)



SPM320 LimeGreen (G)



SPM320 CherryPink (C)



SPM320 SkyBlue (M)



SPM320 Black (B)



SPM370 Milky Blue (SB)



SPM370 Translucent Yellow (SY)



SPM370 Translucent Red (SR)

Compact metronome with clear, loud sound

DM50

Clip-on Digital Metronome

- Tempo Range : 30~250 (221 Steps)
- Beat : 0, 1, 2, 3, 4, 5, 6, 7
- Rhythm :
- Volume Control (4 levels)
- Clock Function



Silver Metallic (S)



Red Metallic (R)



Blue Metallic (L)



Portable and Versatile

DM70

Pocket-Sized Digital Metronome

- Tempo Range : 30~250 (221 Steps)
- Beat : 0, 1, 2, 3, 4, 5, 6, 7
- Rhythm :
- Sound Generation : C4~B4 (A4=440Hz)
- Volume Control (4 levels)
- Built-in Stand



Silver (S)



Blue (L)



Black (B)

Highly visible tempo indicator with scanning lights

DM100

Multi-Function Digital Metronome with Tap in beat Function

- Tempo Range : 30~250 (221 Steps)
- Beat : 0, 1, 2, 3, 4, 5, 6, 7
- Rhythm :
- Sound Generation : C4~B4, A4=410~450Hz
- Volume Control
- TAP Function
- Back Slot to Fit and Slide Easily onto Music Stand
- Built-in Stand



Silver (S)



Black (B)



High Quality Sound from Dynamic Speaker with Volume Control

SQ50V

Quartz Metronome with Easy to operate Tempo Dial

- Tempo Range : 40~208 (39 Steps)
- Sound Generation : A4 (440Hz), B♭4 (466.16Hz)
- Volume Control
- Two Types of Tempo Sounds



Multi-Function Quartz Metronome with a clear, loud sound

SQ70

Scanning Tempo Indicator with 9LEDs and Tempo Dial

- Tempo Range : 40~208 (39 Steps)
- Beat : 0, 1, 2, 3, 4, 5, 6
- Sound Generation : A4 (440~446Hz), B♭4 (466.16Hz)
- Volume Control
- Two Types of Tempo and Beat Sounds



SEIKO Specifications

Tuners								Tuner & Metronome
	SAT1100	SAT800	STX2	ST01	ST02	SAT501	SAT101	STMX1
Tuning Method (Mode)	<ul style="list-style-type: none"> •Auto-Chromatic Mode •Manual-Chromatic Mode •Sound Mode 		•Auto-Chromatic Mode	•Auto-Chromatic Mode		<ul style="list-style-type: none"> •Auto-Chromatic Mode •Manual-Chromatic Mode •Sound Mode 	<ul style="list-style-type: none"> •Auto Tuning Mode •Manual Tuning Mode •Sound Mode 	<ul style="list-style-type: none"> •Auto-Chromatic Mode •Manual-Chromatic Mode •Sound Mode
Tuning Range	A0 (27Hz)~C8 (4186Hz) (Note=C,C#,D,D#,E,F,F#,G,G#,A,A#,B)	A0 (27Hz)~C8 (4186Hz) (Note =C,C#,D,D#,E,F,F#,G,G#,A,A#,B)	A0 (27Hz)~C8 (4186Hz) (Note = C,C#,D,D#,E,F,F#,G,G#,A,A#,B)	A0 (27Hz)~C8 (4186Hz) (Note = C,C#,D,D#,E,F,F#,G,G#,A,A#,B)		A0 (27Hz)~C8 (4186Hz) (Note = C,C#,D,ED,E,F,F#,G,G#,A,Bb,B)	<ul style="list-style-type: none"> •Guitar : 7B,6E,5A,4D,3G,2B,1E •Bass : LowB,4E,3A,2D,1G,HIC 	A0 (27Hz)~C8 (4186Hz) (Note = C,C#,D,D#,E,F,F#,G,G#,A,A#,B)
Sound Generation	C4~B4 (12 Notes)	C4~B4 (12 Notes)	————	————		C4~B4 (12 Notes)	<ul style="list-style-type: none"> •Guitar : 7B,6E,5A,4D,3G,2B,1E (1 octave higher) •Bass : LowB,4E,3A,2D,1G,HIC (2 octave higher) 	C4~B4 (12 Notes)
Pitch Shift	A4 = 410~450Hz (1Hz Step)		A4 = 415Hz,435~446Hz (1Hz Step)	A4 = 440Hz	A4 = 442Hz	A4 = 410~450Hz (1Hz Step)	A4 = 435~446Hz (1Hz Step)	A4 = 410~450Hz (1Hz Step)
Indicator	<ul style="list-style-type: none"> •LCD Display : Power reserve indicator, Backlight mode mark, Mode Indication, Pitch indication •2 LEDs : Tuning Guide 12LEDs : Note Indication 	<ul style="list-style-type: none"> •LCD Display : Analogous Meter (+/-50 Cent), Digital Cent Indication (+/-50 Cent), Calibration Indication, Mode Indication, Note Indication •3 LEDs : Tuning Guide 	<ul style="list-style-type: none"> •LCD Display : Note Indication, Pitch Indication •9 LEDs : Tuning Guide 	<ul style="list-style-type: none"> •LCD Display : Note Indication •1 LED : Tuning Guide 		<ul style="list-style-type: none"> •String Name Indication (SAT101) 		<ul style="list-style-type: none"> •LCD Display : Mode Indication, Note Indication •7 LEDs : Tuning Guide
Terminal	<ul style="list-style-type: none"> •Built-in Microphone •Input-Jack •Output-Jack 	<ul style="list-style-type: none"> •Input-Jack •Output-Jack 	<ul style="list-style-type: none"> •Built-in Vibration Sensor •Sensitivity Modulate Function 	<ul style="list-style-type: none"> •Built-In Microphone 		<ul style="list-style-type: none"> •Built-in Microphone •Input-Jack •Output-Jack 	<ul style="list-style-type: none"> •Input-Jack •Output-Jack 	<ul style="list-style-type: none"> •Built-in Vibration Sensor •Built-in Microphone
Others	<ul style="list-style-type: none"> •Auto Power-Off •Memory Back Up •Pointer Position Calibration 	<ul style="list-style-type: none"> •Auto Power-Off •Memory Back Up •Backlight 	<ul style="list-style-type: none"> •Auto Power-Off •Memory Back Up 	<ul style="list-style-type: none"> •Auto Power-Off 		<ul style="list-style-type: none"> •Auto Power-Off •Memory Back Up 	<ul style="list-style-type: none"> •Auto Power-Off •Memory Back Up 	<ul style="list-style-type: none"> •Auto Power-Off •Memory Back Up
Battery	R03/LR03(AAA)×2(3V) included		Lithium Battery(CR2032×1) included	Lithium Battery(CR1220×1) included		R03/LR03(AAA)×2(3V) included		————

Metronomes								
	WPM1000・2000	SPM320・370	SQ70	SQ50V	DM100	DM70	DM50	
Tempo Range	40~208 times/min.(39 Steps)				30~250 times/min.(221 Steps)			30~250 times/min.(221 Steps)
Beat and Rhythm	0,2,3,4,6	————	0,1,2,3,4,5,6	————	0,1,2,3,4,5,6,7	0,1,2,3,4,5,6,7	0,1,2,3,4,5,6,7,8,9	
Sound Generation	————	————	A4 = 440~446Hz (1Hz Step)	A4 = 440Hz B♭4 = 466.1Hz	C4~B4 (12 Notes) A4 = 410~450Hz (1Hz Step)	C4~B4 (12 Notes) A4 = 440Hz	————	A4 = 410~450Hz (1Hz Step)
Tempo & Beat Sound	Click & Bell		2 different selectable tones		Click Sound	Beep		————
Indicator	————	————	9 LEDs	1 LED	5 LEDs & LCD	1 LED & LCD	————	7 LEDs & LCD
Terminal	————	————	<ul style="list-style-type: none"> •Earphone Jack (φ 3.5mm) •AC Adapter Jack (DC9V) 	<ul style="list-style-type: none"> •Earphone Jack (φ 3.5mm) 	————	<ul style="list-style-type: none"> •Earphone Jack (φ 2.5mm) 	————	————
TAP Function	Tempo Range	————	————	————	30~250	————	————	————
	Rhythm	————	————	————		————	————	————
Others	————	————	<ul style="list-style-type: none"> •Volume Control •Memory Back Up 	<ul style="list-style-type: none"> •Volume Control 	<ul style="list-style-type: none"> •Volume Control •Memory Back Up 	<ul style="list-style-type: none"> •Volume Control (4levels) •Memory Back Up 	<ul style="list-style-type: none"> •Volume Control (4levels) •Clock •Memory Back Up 	<ul style="list-style-type: none"> •Auto Power-Off •Volume Control •Memory Back Up
Battery	————	————	9V Dry Battery (6F22) included		R03/LR03(AAA)×2 included	Lithium Battery(CR2025×1) included		Lithium Battery(CR2032×1) included

Accessories	
	STM-20
Terminal	Input-Jack (φ 6mm)
Cable Length	150cm

AVAILABLE AT:

SEIKO SEIKO SPORTS LIFE CO.,LTD.

17-8,Nishikata 1-chome,Bunkyo-ku,Tokyo 113-0024, Japan
<http://www.seiko-sl.co.jp/music>

SEIKO IS A REGISTERED TRADEMARK OF SEIKO HOLDINGS CORPORATION, JAPAN.