


# PLEASE READ BEFORE USE


## 1) Contrast Adjustment

ER-8000 features a contrast adjustment wheel on the right hand side of the product. This enables you to easily obtain the best contrast from the display under different light conditions. However it is possible to misalign. Should the display become too dark or too light, please check and adjust the contrast wheel accordingly. Please refer to pages 6-7, point 21 in the instruction manual for further details.



## 2) Low Battery Indicator Symbol

The battery mark is not a moving indicator of the power level remaining in the batteries. It is only a symbol displayed to indicate that battery power is low and that the unit will soon require fresh batteries. (See page 2 of the instruction manual to change batteries - Remember to always press the reset button whenever new batteries are installed).



**NOTE** : If the contrast is set too dark, the battery mark (together with the up and down arrows) may be visible along with other elements of the LDC display. Please therefore check the contrast wheel (above) has been set correctly before changing the batteries.